

# スーパーリモコンマイク



**マイク**  
はなす ときは ここに  
むかって はなそう。

このライトが  
ひかかったら  
マイクに むかって  
はなそう。

**まるボタン**  
やりなおす ときに  
おそう。

**さんかくボタン**  
ろくおんした うたを  
さいせいして  
きく ときに つかおう。  
さいせいしている ときに  
おすと、 おすたびに  
こえが かわるよ。

**スピーカー**  
おとが きこえて  
くるから みみを  
ちかづけないでね。

**パワースイッチ**  
でんげんを 入れたり  
きったりするよ。  
おんりょうの  
ちようせつも できるよ。



<クイズモード>  
**たんご** **フレーズ** えいごの クイズで あそべる。

<うたモード>  
**うた1** **うた2** **うた3** うたを ろくおんできるよ。

**つうしん** I がつごうから つかえるから まっていてね。

## スーパーリモコンマイクを つかってみよう!

クイズを だす  
みすたあばんぷきん



### クイズモード たんご フレーズ で あそぼう!

たんご/フレーズを きいて クイズの こたえを いってみよう。


- ①でんげんを 入れる。▶ ②たんご モードに する。



いろいろなもの  
うっているのは どっち?  
fire station supermarket



- ③クイズを よく きく。



もういちど もんだいを  
ききたい ときは  
まるボタンを  
おそう!

- ④「こたえを えいごで  
いってみよう!」の こえの  
あとで あかい ライトが  
ひかかったら、



- ⑤こたえを マイクに  
むかって いう。

⑥こたえを きく。  
ただしい こたえを  
えいごで いえたかな?

こたえは...「きみの こたえを  
さいてみよう」の あとに わかるよ!

キラッ! きいてみよう!

supermarket  
マイクが こたえを  
おしえてくれるよ。



フレーズ モードでも あそんでみてね。

### うたモード うた1 うた2 うた3 で あそぼう!

おてほんの うたを きいて マイクに むかって うたってみよう!

- ①でんげんを 入れる。▶ ②うた モードに する。



- ③おてほんを きく。

もういちど やりなおしたい ときは まるボタンを おそう!



- ④いっしょに うたう。



- ⑤きく。

さいせいしている  
ときに さんかくボタンを  
もう いちど おすと、  
ろくおんした こえが  
かわるよ。  
やってみてね!

**うた1 10 Little Cookies**  
One little, two little, three little cookies  
Four little, five little, six little cookies  
Seven little, eight little, nine little cookies  
Ten little cookies are here

**うた2 This is the Way**  
This is the way I go to school  
Go to school, go to school  
This is the way I go to school  
La, la, la, la, la, la

**うた3 BINGO**  
There was a farmer had a dog  
And Bingo was his name, oh!  
B-I-N-G-O  
B-I-N-G-O  
B-I-N-G-O  
And Bingo was his name, oh!